
Shelfology Certified Rad_

Designed & Crafted By Radically Talented Humans Right Here In The U.S. Of Awesome_

U.S. Patent No. 20240090667_



Aksel System Install Guide





Table of Contents	Page
Installation Steps	004
Warnings	006
Rad Tips	007



Aksel System Install Guide Introduction

GET MORE RADNESS NOW AT SHELFOLOGY.COM Need a Hand? 949.244.1083 // Hello@Shelfology.com



Aksel S

DESIGNED s

œ

CRAFTED HERE

> BY RΑI

.s

ę

- ANESOME


EAD

FAS

RIGHT

. COM

Installation Steps




Let's dive in, homies! First, remove set screws. Next, remove Aksel bracket from the back of the shelf. Put shelf and set screws aside.

Orient your bracket on the wall so the hole and channel pattern across the top of your bracket face up. Use a drill to install a fastener in either far left or right hole. Review **Rad Tip** (\oplus on page 7 to know how to use your included fasteners. Level your bracket, set another fastener in the opposite end hole with your drill. If you have installed blocking behind the full length of your bracket, skip to step 5. If you have not installed blocking, proceed to step 3. For more information on blocking, see **Rad Tip** (\oplus on page 7.

Mark all fastener holes and channels with a pencil. Once every fastener location has been marked, uninstall both fasteners and remove your bracket from the wall. Take a swig of your favorite soda or non-alcoholic brew.

If you need to align multiple shelves, every Aksel bracket has an etched centerline mark in the center-top of the backbar. Use a level to create a vertical centerline on your wall and align your brackets to this line.

GET MORE RADNESS NOW AT SHELFOLOGY.CO Need a hand? 949.244.1083 // Hello@Sh



Use a stud finder to mark the location of every stud the bracket crosses. Then for areas between studs, mark one or two drywall anchor install locations roughly every eight to twelve inches (they may be closer if you have additional fasteners), along the length of the bracket depending on the stud spacing in your wall.

Predrill each drywall anchor location with a ¼" drill bit to avoid breaking drywall anchors. Install a drywall anchor in each of these pre-drilled locations. If you are using your own anchors, we recommend Toggler brand for best results. Stud locations should not be pre-drilled. Drywall anchors should be installed flush with the drywall surface.

Replace the bracket and install a truss head fastener into every location crossing a stud or blocking. Install pan head fasteners into every location where wall anchors are used. **See Rad Tip** (on page 7 to ensure you are using the correct fastener. Take another swig of that sweet, sweet soda...you get me?

Make a final inspection of your bracket. Check for bracket sag, confirm bracket is correctly secured to wall. To correct sag, see **Rad Tip** (2) and (2) on page 7. Slide wood shelf onto bracket. Re-install set screws with phillips screwdriver. Do not use power drill for set screw installation.

Finish off your soda, it's time to celebrate your innate awesomeness! You finished the shelf install and deserve heaps of adulation. If you need more help, please reach out to a shelf geek today.

hello@shelfology.com 949.244.1083 IGNED & CRAFTED BY RADICALLY TALENTED ANS RIGHT HERE IN THE U.S. OF AWESOME.

LIGHTNING FA

5

Ш

AT SH .1083

NESS NOW 949.244.

HAND?

4

GET A NEED

NORE

Whoa, you made it! We are vicariously stoking for you right now. Post your sweet shelfie on Instagram now!

@shelfology #radshelfie

Need a hand? Speak with a Shelf Geek at 949.244.1083 or hello@shelfology.com today.

How did we do? You'll get

an email soon asking for a product review, and we'd be stoked if you oblige. You rock in advance!



① Correct Install Required For Safe Use ⑧ Adhere To The Capacity Rating Of Your Specific Bracket ③ California Proposition 65 Warning ④ This Product May Make Others Incredibly Jealous

1.1 Shelf brackets must be correctly installed into studs or wall blocking. Failure to do so may result in sagging shelves, falling objects, or serious injury. 2.1 Every Shelfology bracket weight class and length has been engineered for use with specific shelf capacities/dimensions. Failure to follow our specified capacity ratings and correct shelf dimensions may result in sagging shelves, falling objects, or serious injury. For more information, reference the Aksel Specifications Sheet. 3.1 This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Don't eat this bracket. If you live outside of California, do whatever you want. For more boring information, visit www. p65warnings.ca.gov. 4.1 Any Shelfology Certified Rad™ product should be flaunted with caution around friends, loved ones, and even complete strangers, as minimal or extreme jealousy may occur. Shelf responsibly.

P.006

Rad Tips

æ



② Using Shims With Your Bracket

③ Optional Fastener Shim Method

④
How To
Choose Your
Fastener Type



1.1 Studs are the vertical 2x4 boards that make up the bones of your walls. They provide solid structure for your shelves to attach to.



1.2 Blocking is typically added later between studs in the wall for additional support to mount shelves to, and is usually made from 2x4 or 2x6 lumber.



1.3 For a contractor grade install with best substrate strength, install blocking along the length of your bracket.



2.1 If your wall is not straight, use shims to ensure your bracket is installed straight across the wall face and square to the wall. The shelf slab and bracket will properly mate only if the bracket is straight and plum.



2.2 If your bracket continues to sag after correct install, use wood shims underneath the backbar to adjust front to back level.



3.1 As another option, wall fasteners may be installed behind the bracket's bottom channels and used as adjustable shims. These should only be used in locations backed by a stud or blocking. Drywall anchors will not offer enough support once real force is applied.

Once your bracket has been positioned on the wall, simply mark the lower slots with a pencil where they cross a stud or blocking, then remove your bracket and begin installing fasteners in the marked locations.



3.2 Once your bracket is reinstalled over the top of these fastener shims, use your drill to make small adjustments to how proud each fastener head rests.



4.1 Truss Head: Use the supplied truss head style wood fasteners in areas that cross studs or blocking with holes and channels that are not countersunk.



4.2 Pan Head: For drywall or masonry, use the supplied pan head fasteners with the included drywall or masonry anchors.



4.3 Bugle Head: We offer a pro install countersink option that allows you to use bugle head fasteners for a flush finish on the backbar. A flush fastener head means less slab milling or easier finish substrate install over the bracket backbar.

윾

ESOME

ALEN

÷

IGH

Aksel System Insta

P.007



Need a hand? Speak with a Shelf Geek at 949.244.1083 or hello@shelfology.com today.

How did we do? You'll get an email soon asking for a product review, and we'd be stoked if you oblige. You rock in advance!

Call Email Shop Visit Social 949.244.1083 hello@shelfology.com www.shelfology.com 156 N 2nd E Rexburg, ID 83440 @shelfology

