

Shelfology  
Certified Rad™

Designed &  
Engineered In The  
U.S. Of Awesome\_

→ Patent  
Pending  
✓ Design.

⚡ Lightning  
Fast Lead  
→ Times.

# Yuri XD Bracket

## Install Guide







Installation  
Difficulty  
Rating (1-10)



5

Table of Contents	Page
Construction Method	004
Installation Steps	005
Rad Tips	008
Notes	009
Warnings	011

Required  
Tools



Optional  
Tools



+

+

+

+

+

+

+

+



START ↓↓

Unleash the potential  
of your floating desk  
dreams with Yuri XD.  
Experience insane  
strength worthy of  
Clark Kent himself.  
Designed & Engineered  
In The U.S. Of  
Awesome. Rad!

## What's In The Box



## What You'll Need






# Construction Method


① Pick Your Depth

② Use Any Desk Style

③ Hold Massive Weight




Bracket Rod Length	Desk Depth (D)
12" (XD)	12"–18"
18" (XD)	18"–24"
24" (XD)	24"–30"



Weight capacity varies by desk depth, mounting surface and the number of fasteners secured through the bracket. Brackets must be installed correctly into studs and blocking. See **Figure 1** below.

Nearly any desk slab size, shape, or design will work with the Yuri Bracket as support. We recommend spacing brackets every 32" or less.


Figure 1: Yuri Bracket Weight Capacities






# Installation Steps

001




Yo, here we go! Position your first bracket on a stud or post in the desired location. See **Rad Tip** ① on page 8. Predrill lagscrew location using a  $\frac{1}{8}$ " drill bit. Install a  $\frac{1}{4}$ " lagscrew into an upper fastener hole.

002



Straighten the bracket using a level. Mark a lower fastener hole location with a fastener tip or a pencil. Predrill location with  $\frac{1}{8}$ " drill bit.


003



Install a second lagscrew into second location. Recheck for level. Predrill and install lagscrews into remaining holes.




004




After installing your first bracket, hold the second bracket in position. We recommend spacing brackets 2" or less apart. Use a level to align both brackets horizontally. Mark an upper fastener hole location for the second bracket. See **Rad Tip**® on page 8.

005




Install upper lag screw in marked location. Repeat steps 2 and 3. Once you have installed all brackets, you are ready for drywall.

006



To finish your installation, measure and cut holes in your drywall or wall sheeting large enough to accept the bracket supports. Move wall sheeting into place around brackets and secure it to the wall.


007



If needed, seal gaps around bracket supports with drywall joint compound. See **Rad Tip**® on page 8. Texturing and painting the wall surface behind the desk slab is recommended before desk installation.




008



Position desk slab. You may choose to install set screws or use silicone to secure it in place. See **Rad Tip ④** below for more information and for slab recommendations.

009



You are done! give your cat a celebratory fist bump if present. Gently place your authentic 1980's high-heel shoe phone on desk and admire.

**Whoa, you made it! We are vicariously stoking for you right now. Post your sweet shelfie on Instagram now!**


**@shelfology**  
**#radshelfie**

Need a hand? Speak with a Shelf Geek at 949.244.1083 or [hello@shelfology.com](mailto:hello@shelfology.com) today.


How did we do? You'll get an email soon asking for a product review, and we'd be stoked if you oblige. You rock in advance!



## ① Fasten into Studs



**1.1** The Yuri bracket is designed to be mounted on a fixed stud, post, or other structural surface. Drywall is not structural, and will not support this bracket.




**1.2** Predrilling a  $\frac{1}{8}$ " pilot hole in the desired lagscrew location will ensure accurate fastener placement, and prevent splitting of the stud or post.

## ② How to Make a Longer Level



**2.1** You can turn a short level into a long one by laying it on a straight object like a yard stick. Just hold it in place with your bullet level on top and measure!

## ③ Protecting the Finish




**3.1** Covering the bracket support rod with low-tack removable tape will protect the finish during drywall installation, sanding, and painting. Remove tape before installing desk.

**3.2** If you did not order set screw holes with your bracket, this is a perfect time to use a  $\frac{1}{8}$ " drill bit and drill out two lovely set screw locations for a solid slab install.

## ④ Securing the Right Slab



**4.1** At least  $\frac{3}{4}$ " thick solid hardwood, or manufactured desk slab is recommended to avoid sag. See [shelfology.com](http://shelfology.com), or call 949-244-1083 to order slabs made to measure.



**4.2** To secure your slab to the brackets, we recommend drilling at least two vertical holes in each support rod with a  $\frac{3}{16}$ " drill. Install set screws through these locations.





# YuriXD Bracket Install Guide Notes

DESIGNED & ENGINEERED IN  
THE U.S. OF AMERICA.

**LIGHTNING FAST  
LEAD TIMES.**

## Notes



GET MORE RADNESS NOW AT SHELFOLGY.COM  
NEED A HAND? 949.244.1083 // HELLO@SHELFOLGY.COM\_

P.010

## Notes



# Warnings



## Yuri XD Bracket Install Guide Warnings

- ①

**Correct Install  
Required For  
Safe Use**
- ②

**Adhere To  
The Capacity  
Rating Of  
Your Specific  
Bracket**
- ③

**California  
Proposition 65  
Warning**
- ④

**This Product  
May Make  
Others  
Incredibly  
Jealous**

1.1 Desk brackets must be correctly installed into studs or wall blocking. Failure to do so may result in sagging desks, falling objects, or serious injury.

2.1 Every Shelfology bracket weight class and length has been engineered for use with specific capacities/dimensions. Failure to follow our specified capacity ratings and correct desk dimensions may result in sagging desks, falling objects, or serious injury. For more information, refer to the Yuri XD specification sheet.

3.1 This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Don't eat this bracket. If you live outside of California, do whatever you want. For more boring information, visit [www.p65warnings.ca.gov](http://www.p65warnings.ca.gov).

4.1 Any Shelfology Certified Rad™ product should be flaunted with caution around friends, loved ones, and even complete strangers, as minimal or extreme jealousy may occur. Shelf responsibly.

DESIGNED & ENGINEERED IN  
THE U.S. OF AWESOME.

LIGHTNING FAST  
LEAD TIMES.

**Need a hand? Speak with a Shelf Geek at 949.244.1083 or [hello@shelfology.com](mailto:hello@shelfology.com) today.**

**How did we do? You'll get an email soon asking for a product review, and we'd be stoked if you oblige. You rock in advance!**

Call	949.244.1083
Email	<a href="mailto:hello@shelfology.com">hello@shelfology.com</a>
Shop	<a href="http://www.shelfology.com">www.shelfology.com</a>
Visit	156 N 2nd E Rexburg, ID 83440
Social	@shelfology

